

1250 Automatic Towel Dispenser Installation Guide

Mounting Instructions

1. Position the stainless steel mounting plate on the wall.
 - a. Make sure there is enough room to access the controls and for the cabinet to be opened fully once mounted.
2. Attach the mounting plate to the wall with the enclosed fasteners.
3. Slide the towel dispenser cabinet over the 4 tabs on the mounting plate.
4. Open the towel cabinet and secure the cabinet to the mounting plate by inserting the machine screw through the small hole at the top center of the cabinets back.

Operation Instructions

1. Once the towel cabinet has been mounted to the wall, open the front door of the cabinet and remove the battery housing.
2. Install 4 “D Size” Alkaline Batteries (per the illustration) in the battery housing.
(Normal battery life-span will be from 4000 to 6000 cycles.)
 - a. When sensor light is flashing RED batteries need to be replaced.
3. Reinstall the battery housing in the towel cabinet, and lock in place.
4. Install a roll of paper towels in the towel dispenser. (Towels can be 8” to 8.5” outside diameter, with a core diameter of 1.5” to 3”) Follow the instructions on the inside back wall of the towel dispenser for proper towel installation.

Note: If you are using roll towels with a 1.5” core you will need to remove the 2” core adapters from both paper supports. Hold the 3” paper support hub and turn the 2” hub clockwise to disengage. Store the 2” core adapters in a safe place so they can be reinstalled if necessary.

Control Settings

There are 4 control switches located on the right-hand side of the cabinet as you face the cabinet.

- 1. Auto Feed Switch (Push button to advance paper)**
- 2. Paper Feed Time Delay**
 - a. S = 2 seconds
 - b. M = 4 seconds
 - c. L = 6 seconds
- 3. Paper Length Setting**
 - a. S = 8 ¾”
 - b. M = 10 ¼”
 - c. L = 12”
- 4. Distance Sensitivity Setting for Electronic Sensor (to recognize hands)**
 - a. S = ¾”
 - b. M = 1 ½”
 - c. L = 2 ½”